

ePrint 対応プリンター一覧

◆iPhoneからプリントサーバーなしでダイレクト印刷が可能な機種

Artisan 700	Epson Stylus NX510	EPSON STYLUS PHOTO PX800FW	Epson Stylus TX550W
Artisan 710	Epson Stylus NX515	Epson Stylus Photo PX810FW	EpsonME OFFICE 650FN
Artisan 800	Epson Stylus Office BX310FN	EPSON STYLUS PHOTO TX700W	PM-T960
Artisan 810	EPSON STYLUS OFFICE BX600FW	Epson Stylus Photo TX710W	PM-T990
EP-802A	Epson Stylus Office BX610FW	EPSON STYLUS PHOTO TX800FW	PX-502A
EP-901F	Epson Stylus Office TX510FN	Epson Stylus Photo TX810FW	PX-601F
EP-902A	EPSON STYLUS OFFICE TX600FW	Epson Stylus SX510W	WorkForce 310
EP-902A	Epson Stylus Office TX610FW	Epson Stylus SX515W	WorkForce 600
Epson ME OFFICE 650FN	EPSON STYLUS PHOTO PX700W	EPSON STYLUS SX600FW	WorkForce 610
EPSON ME OFFICE 700FW	Epson Stylus Photo PX710W	Epson Stylus SX610FW	

◆iPhoneからプリントサーバー経由で印刷が可能な機種

E-150	EPSON STYLUS CX9300F	EPSON STYLUS PHOTO RX585	PM-A840
E-200	EPSON STYLUS CX9400Fax	EPSON STYLUS PHOTO RX590	PM-A890
E-300	EPSON STYLUS DX3800	EPSON STYLUS PHOTO RX595	PM-A920
E-300L	EPSON STYLUS DX3850	EPSON STYLUS PHOTO RX610	PM-A940
E-330	EPSON STYLUS DX3850plus	EPSON STYLUS PHOTO RX615	PM-A950
E-500	EPSON STYLUS DX4000	EPSON STYLUS PHOTO RX640	PM-A970
E-520	EPSON STYLUS DX4050	EPSON STYLUS PHOTO RX650	PM-D600
E-530C	EPSON Stylus DX4200	EPSON STYLUS PHOTO RX680	PM-D800
E-530P	EPSON Stylus DX4250	EPSON STYLUS PHOTO RX685	PM-D870
E-530S	EPSON Stylus DX4800	EPSON STYLUS PHOTO RX690	PM-G4500
E-600	EPSON Stylus DX4850	Epson Stylus Photo TX650	PM-G850
E-700	EPSON Stylus DX4850plus	Epson Stylus Photo TX659	PX-501A
E-720	EPSON STYLUS DX5000	EPSON STYLUS SX200	PX-5600
E-800	EPSON STYLUS DX5050	EPSON STYLUS SX205	PX-A620
EP-702A	EPSON STYLUS DX6000	Epson Stylus SX210	PX-A640
EP-801A	EPSON STYLUS DX6050	Epson Stylus SX215	PX-A650
EPSON CX7300	EPSON STYLUS DX7400	EPSON STYLUS SX400	PX-A720
EPSON CX7310	EPSON STYLUS DX7450	EPSON STYLUS SX405	PX-A740
Epson ME OFFICE 510	EPSON STYLUS DX8400	Epson Stylus SX410	PX-FA700
EPSON ME OFFICE 600F	EPSON STYLUS DX8450	Epson Stylus SX415	PX-G5300
EPSON ME PHOTO 20	EPSON STYLUS DX9400F	EPSON STYLUS TX200	WorkForce 500
EPSON STYLUS CX2800	EPSON STYLUS DX9400F WiFi edit	EPSON STYLUS TX203	
EPSON STYLUS CX2900	EPSON STYLUS NX200	EPSON STYLUS TX209	
EPSON STYLUS CX2905	Epson Stylus NX215	Epson Stylus TX210	
EPSON STYLUS CX3700	EPSON STYLUS NX300	Epson Stylus TX213	
EPSON STYLUS CX3800	EPSON STYLUS NX400	Epson Stylus TX219	
EPSON STYLUS CX3805	Epson Stylus NX410	EPSON STYLUS TX400	
EPSON STYLUS CX3810	Epson Stylus NX415	EPSON STYLUS TX409	
EPSON STYLUS CX3900	EPSON STYLUS OFFICE BX300F	Epson Stylus TX410	
EPSON STYLUS CX3905	EPSON STYLUS OFFICE TX300F	Epson Stylus TX419	
EPSON STYLUS CX4000	EPSON STYLUS PHOTO 1400	PictureMate	
EPSON STYLUS CX4050	EPSON STYLUS PHOTO 1410	PictureMate 100	
EPSON STYLUS CX4080	EPSON STYLUS PHOTO 1900	PictureMate 500	
EPSON Stylus CX4100	Epson Stylus Photo PX650	PictureMate Deluxe	
EPSON Stylus CX4200	EPSON Stylus Photo R240	PictureMate PM 200	
EPSON Stylus CX4700	EPSON Stylus Photo R245	PictureMate PM 210	
EPSON Stylus CX4800	EPSON Stylus Photo R250	PictureMate PM 215	
EPSON STYLUS CX4900	EPSON STYLUS Photo R260	PictureMate PM 225	
EPSON STYLUS CX4905	EPSON STYLUS PHOTO R265	PictureMate PM 235	
EPSON STYLUS CX5000	EPSON STYLUS PHOTO R270	PictureMate PM 240	
EPSON STYLUS CX5900	Epson Stylus Photo R2880	PictureMate PM 250	
EPSON STYLUS CX6000	EPSON STYLUS PHOTO R340	PictureMate PM 260	
EPSON STYLUS CX7300	EPSON STYLUS PHOTO R350	PictureMate PM 270	
EPSON STYLUS CX7400	EPSON STYLUS PHOTO R360	PictureMate PM 280	
EPSON STYLUS CX7400V	EPSON STYLUS PHOTO R380	PictureMate PM 290	
EPSON STYLUS CX7450	EPSON STYLUS PHOTO R390	PictureMate PM 300	
EPSON Stylus CX7700	EPSON Stylus Photo RX520	PictureMate PM 310	
EPSON Stylus CX7800	Epson Stylus Photo RX530	PM-840S	
EPSON STYLUS CX8300	EPSON STYLUS PHOTO RX560	PM-A750	
EPSON STYLUS CX8400	EPSON STYLUS PHOTO RX580	PM-A820	